

FLOATING INSTALLATION

INSTALLATION

Uniclic® is unique because panels can be installed in two different ways:

Method A - Angled installation method (see diagrams 1A-1B-1C).

Method B - Horizontal installation method (see diagrams 2A-2B).

TOOLS FOR INSTALLATION OF FLOOR

Standard tools for installing floating floors (i.e. mallet, saw, pencil, tape measure).

Installation kit (crowbar, spacers (1-8 mm/0.039"-0318") and Uniclic®/Divina batten), table saw or cross-cut saw.

INSTALLATION OF THE FLOOR

1. First install a protective barrier against moisture (PE film) and join the rows with tape (see diagram 3A).
2. Start the first row with an entire panel.
First cut the tongue to the length and width of the panel (see diagram 3B).
3. Place the panel with the side on which the tongue was cut against the wall.
4. Put spacers from the installation kit between the panels and the wall (see diagram 3C).
The diagram indicates where the Uniclic® panels are joined using the angle technique or by blows applied to the panels (see diagrams 4A-4F).

In places where it is difficult to install the Uniclic® panels with the batten (e.g. against the wall), you may join them using a crowbar and mallet (see diagrams 5A-5B).

FINISH

Remove the spacers.

Install the skirting on the PE film making a round shape with the wall (see diagram 8A).

